

Multi-Contact

MC

STÄUBLI

User Guide New CombiTac Configurator

Building Our Success




Agenda

1	Step-by-step configuration
2	Settings

Agenda

1	Step-by-step configuration
2	Settings

Along the configuration, let the system drive you through your journey.



Step-by-step configuration

Select a type of configuration

1.1 Housing Type 1.2 Housing pin 2 Module 3 Extras 4 Offer

Select type of housing

Panel mount



Panel mount

DIN housing



IP65 aluminum



IP68/69K



IP65 plastic

Special housing



Lighthouse

→ Directly in module-page, empty 3D

→ Select shape of housings in next pages

Scroll down to see special housing
→ Only Lighthouse, so directly in module-page, empty 3D

Step-by-step configuration

Create a first module : select a contact category




→ 3D view, interactivity starts when first first module is added

- Select a category of module
- Power
up to 300 A / 1000 V
 - High voltage
up to 32 A / 5 kV
 - Signal
up to 19 A / 600 V
 - Monitoring
Last Mate First Brake
 - Coaxial
up to 50 Ω / 6 GHz
 - Data transfer
Ethernet... bis 10Gbit
 - Optical fiber
glass / plastic optical fiber
 - Thermocouple
thermocouple pressure contacts
 - Pneumatic and Fluid
from 3 to 8 mm / with or without shut-off valve
 - Earthing
from 3 to 8 mm
 - Spacer

→ Selection area
→ First step: select a category of contact

Step-by-step configuration

Create a first module : select a contact



Select contact

→ Different levels of information

RG58 RG316 6.0 GHz SMA
Sub-Miniature-A (termination)

CT-S-COAX-SMA

RG58 2.4 GHz COAX
(termination)

CT-S-COAX-RG58

RG316 2.4 GHz COAX
(termination)


→ Scroll up and down to identify the contact

→ Select with simple click

A screenshot of a contact selection menu. The menu lists three contact options, each with a small 'i' icon to its left. The first option is 'RG58 RG316 6.0 GHz SMA Sub-Miniature-A (termination)' with a corresponding image of an SMA connector and the label 'CT-S-COAX-SMA'. The second option is 'RG58 2.4 GHz COAX (termination)' with a corresponding image of an RG58 connector and the label 'CT-S-COAX-RG58'. The third option is 'RG316 2.4 GHz COAX (termination)'. A callout box points to the first option with the text '→ Different levels of information'. Another callout box points to the second option with the text '→ Scroll up and down to identify the contact' and '→ Select with simple click'.

Step-by-step configuration


Create a first module : select a carrier



A screenshot of the configuration interface for selecting a carrier. The interface shows a list of options under the heading 'Select carrier'. Two options are visible: '2-pole carrier' (CT-E-COAX-2) and '1-pole carrier' (CT-E-COAX-1). Each option includes a small 3D image of the carrier and an information icon (i). Callouts provide instructions: '→ Same level of information as previously' points to the information icon, '→ Scroll up and down to identify the carrier' points to the list, and '→ Select with simple click' points to the carrier image.

Step-by-step configuration

Add a module



Module overview / 1


≡ 1. CT-E-COAX-2 📄 🗑️ ⓘ

Add new module

- Click to add a module
- Then again category – contact – carrier

Step-by-step configuration

Duplicate or remove module : 1st possibility



→ Icons for duplicating or removing a module


Module overview / 1

≡ 1. CT-E-COAX-2   


Add new module

Step-by-step configuration

Duplicate or remove module : 2nd possibility




→ Click on module to open detailed view
→ Module can be selected on selection area or on 3D




→ Icons for duplicating or removing a module

Step-by-step configuration

Edit module



- Click on module to open detailed view
- Module can be selected on selection area or on 3D



- Contact can be selected on selection area or on 3D
- Select contact with simple click (as previously)

Step-by-step configuration

Change position of modules



Staubli Electrical Connectors - In | CombiTac Alpha

https://combitac.ec.staubli.com/module/?id=JeGPyto_EFvx31h-vMwt0

CombiTac Configurator

Bug Melden

STÄUBLI

1.1 IP68/69K | 1.2 IP68/69K aluminum (45°) coupler hood | 1.3 IP68/69K aluminum pedestal mount | **2 Module** | 3 Extras | 4 Offer

Module overview / 1

- 1. CT-E-COAX-2
- 4. CT-NET-1/S
- 2. CT-E1,5-5
- 3. CT-E8-4/S

Add new module


Next >

→ Module can be selected on selection area or on 3D

→ Drag & drop at desired position

Step-by-step configuration

Last step before extras



→ As per default, Dips are positioned on the right hand side
 → Position of dips can be changed with Drag & drop (as previously)

Module overview / 1

1. CT-E-COAX-2	+	✖	ⓘ
2. CT-NET-1/S	+	✖	ⓘ
3. CT-E1,5-5	+	✖	ⓘ
4. CT-E8-4/S	+	✖	ⓘ
5. CT-DIP4	+	✖	ⓘ
6. CT-DIP4	+	✖	ⓘ
7. CT-DIP4	+	✖	ⓘ
8. CT-DIP4	+	✖	ⓘ
9. CT-DIP4	+	✖	ⓘ
10. CT-DIP2	+	✖	ⓘ

Add new module


→ Click on next to add Dips

Next >

→ Once modules & dips are at right position, click on next

Step-by-step configuration

Select extras



Endpieces

Protection wall

Boreholes

→ Select extras (self-explanatory)

Next >

→ Next to go to Offer page

Step-by-step configuration

Finalise configuration



→ Add information as usual

Quantity of male parts:

Quantity of female parts:

Quantity Parking Station:

Assembly instruction language:

Order housing(s):

Coding:

Application:

Modify Reset Send

Part List

Pos	Order Number	Name	Description
-----	--------------	------	-------------

Housing

Pin	33.6872	CT-TG2-S IP68 HE	IP68/69K aluminum (45°) coupler hood
Soc.	33.6862	CT-SG2 IP68 HE	IP68/69K aluminum pedestal mount

Endpieces

Carrier row 1 Pin side

1	33.4000	CT-E8-2 / 8mm elect.	2-pole carrier
1	33.0505	CT-SP8/25 AU	100 A crimp termination 25 mm² AWG 4
2	33.0505	CT-SP8/25 AU	100 A crimp termination 25 mm² AWG 4
2	33.4000	CT-E8-2 / 8mm elect.	2-pole carrier
1	33.0504	CT-SP8/25 AG	100 A crimp termination 25 mm² AWG 4
2	33.0504	CT-SP8/25 AG	100 A crimp termination 25 mm² AWG 4
	33.4042	CT-DIP4	Spacer 4 mm
		CT-DIP3	Spacer 3 mm

→ Back to edit module page

→ Start from scratch !

→ Finalise before registration

Agenda

1	Step-by-step configuration
2	Settings


Different level of settings – any time available

3D view

→ Switch from plug to socket side

→ Switch from transparent to filled housing

→ Hide/show dimensions




Components view (contacts, carriers and housings)

→ Switch from configurable (old MC) to pre-configured components (FCS)

→ Different level of information:


1. Part-Nr and usual description (bottom)
2. Description based on properties (top)
3. Additional information with mouve-over on
4. Full datasheet by clicking on




Almost no limitation of viewing angles....with a simple mouse

Rotation

Almost 360° side rotation




90° up & down rotation




Zoom / De-zoom

Farthest view



Nearest view



Facing performance problems? Dynamic pop-up to advice how to improve



Facing a performance problem or the software is slow in general?
You can improve the performances:

1. Use Google Chrome as a browser
2. Use hardware accelerator.

Google settings
=> advanced
=> System
=> Use hardware acceleration

System

Continue running background apps when Google Chrome is closed	 <input type="checkbox"/>
Use hardware acceleration when available	<input checked="" type="checkbox"/>
Open proxy settings	

Above mentioned actions should contribute to accelerate the software. Else, please contact your Sales Engineer.